DSC-H1

SONY

LEVEL 2

SERVICE MANUAL

Ver 1.2 2005. 09

DSC-H1

US Model
Canadian Model
AEP Model
UK Model
E Model
Hong Kong Model
Australian Model
Chinese Model
Japanese Model
Korea Model
Tourist Model

SUPPLEMENT-1

File this supplement-1 with the service manual.
(PV05-045)

Precaution on Replacing the SY-127 Board

1. SERVICE NOTE

• PRECAUTION ON REPLACING THE SY-127 BOARD

When you replace to the repairing board, the written data of repairing board also might be changed to original setting.
When the data has changed because of board replaceing etc, check the data setting (VIDEO OUT Default Data) is right. If not, rewrite to the right value.

VIDEO OUT Default Data

Page	Address	Data	
		NTSC	PAL
4F	8D	00	01
4F	A2	00	01

Writing Method:

1) Select page: 00, address: 01 and set data: 01.
2) Select page: 4F, address: 8D and A2, and set the VIDEO OUT Dafault Data.
3) Click SAVE on the SEUS screen.
4) Wait for more than 3 sec.
5) Select page: 80, address: 30, and check that the data is “00”.
6) Select page: 00, address: 01, and set data: 00.

Sony EMCS Co.
2005I1600-1
©2005.09
Published by DI Technical Support Department